



20_b: Master 及 Slave 的 PID 參數調整紀錄


Date: May 21st, 2020

1. TOMCAT 240+400W 馬達展示櫃, 無負載. 電流環, 速度環及位置環測試調件及參數分別如下:
5/21 第 2 次量測

測試條件/參數	上次量測 5/19		這次量測				
	Master	Slave(未調整)	M	M	M	M	M
電流環							
Half Period[s]	0.02		0.02				
Current[%]	50		50				
Kp	613	613	1014	1014	1014	1014	1014
Ki	222	222	233	233	233	233	23
Kd	1	1	1	1	1	1	1
速度環							
Half Period[s]	0.5						
Velocity[RPM]	300						
Kp	878	878	1500	1500	1700	1700	1700
Ki	18	18	30	40	50	50	50
Kd	1	1	1	1	1	1	1
位置環							
Kp	1	1	400	400	400	500	600
Pos. Errors[counts]	900	1800 同動時設定值					
Time Errors[ms]	50	50					
跑位置, 量測跑 180 度位置誤差 counts			170	150	130	118	108
PS:	馬達感覺電流聲較大	馬達感覺電流聲較小					

Master 之相關波型及圖形如下所示

第 2 次(本次)



跑位置, 量測位置誤差

Position

Pos. management: Pos-Tab cyclic


Pos-Tab cyclic



Maximum Speed: 3000 Selection index: ---
 Pos. actual value: 270 Pos number: 3



Cyclic Positions


Mode: Automatic 0009h Max cycles: 1
 Cycle: Cyclic 0009h Index: 4

N?	Position	Velocity	Accel.	Decel.	Time	Abs./Rela.	Vel. mode
1	0	1000	10000	10000	500	Absolute	Tab-rec data
2	90	1000	10000	10000	500	Absolute	Tab-rec data
3	270	1000	10000	10000	500	Absolute	Tab-rec data
4	180	1000	10000	10000	500	Absolute	Tab-rec data
5	262144	1000	10000	10000	0	Absolute	Tab-rec data









Caliper(TOMCAT EVO) Version: 4.22

File Commands Print Language About

2: Dg/Tmc Evo - NTT 01-[TMC]Axis 1

[I.0]Power [I.1]-- [I.2]Jog+ [I.3]Jog- [I.4]Home Pos. [I.5]Reset [I.6]-- [I.7]--

Data Monitor

Drive 6.0-12.0 [230 V]
 Bus Input/OutPut
 Mode [3]Position
 Current 0.00 A
 Temp. 34.9 °C
 Speed [Mot] 0 rpm
 Position (Rev/Offset)[Mot]
 0 0 Counts
 0 Counts

Input

I.0 Power on
 I.1 --
 I.2 Jog+
 I.3 Jog-
 I.4 Home Position
 I.5 Reset Alarm
 I.6 Analog Input 1 9
 I.7 Output 2 --

Output

O.0 Drive OK
 O.1 Speed 0

Menu

- Field Bus
- Motor Data
- Advanced Setup
- Control Set
- Control Setting
- Digital Input
- Factors
- Position Setting
- Position
- Pos Parameters
- Home Position
- Position Jog
- Pos. - Input x
- Main Speed
- GearBox Mode
- Torque
- Electronic Cam
- Press

Drive Data

Position Setting

Pos. error win. 900
 Timeout error [ms] 50

PS: 若將 Master 的 ivt 直接 copy 到 Slave, 則會發生 position error 大於 900 counts 的狀況, 將 Slave 的 position 設為 1600counts, 則下列 Master 的 position table OK. 梯型加減速.

File Commands Print Language About

2)Dg/Tmc Evo - NTT 02-[TMC]Axis 1

(I.0)Power (I.1)Enable Ref. (I.2)Jog+ (I.3)Jog- (I.4)Home Pos. (I.5)Reset (I.6)--- (I.7)---

Data Monitor

Drive 6.0-12.0 [230 V]
 Bus Input/OutPut
 Mode [3]Position
 Current -0.02 A
 Temp. 39.2 °C
 Speed [Mot] 1 rpm
 Position (Rev/Offset)[Mot]
 0 12963 Counts
 12963 Counts

Input

I.0 Power on
 I.1 Enable Ref.
 I.2 Jog+
 I.3 Jog-
 I.4 Home Position
 I.5 Reset Alarm
 I.6 Analog Input 1 10
 I.7 Output 2 --

Output

O.0 Drive OK
 O.1 Target reached
 O.2 Homing attained

Position

Pos. management Pos-Tab cyclic

Pos-Tab cyclic

Maximum Speed 3000 Selection index --
 Pos. actual value 74 Pos number 2


Cyclic Positions

Mode Automatic 0009h Max cycles 1
 Cycle Cyclic 0009h Index 4

Table

N?	Position	Velocity	Accel.	Decel.	Time	Abso./Rela.	Vel. mode
1	0	1000	10000	10000	500	Absolute	Tab-rec data
2	90	1000	10000	10000	500	Absolute	Tab-rec data
3	270	1000	10000	10000	500	Absolute	Tab-rec data
4	180	1000	10000	10000	500	Absolute	Tab-rec data
5	262144	1000	10000	10000	500	Absolute	Tab-rec data

2. 若只量測 Slave 的 position error, 看出來比同動時小.



以下空白



嵐天自動化股份有限公司
i-Maku Automation CO., LTD.



Motors & Digital Drives

謝謝您的選用

E-mail: sales@imaku.com.tw

聯絡人: 范揚昇

手機: 0937583280